



AT Command Reference

80515ST10763A, Rev. 08 – 2016-05-26

TELIT
TECHNICAL
DOCUMENTATION



Stollmann is a Telit brand.

BlueMod+B20/BT2.1

AT Command Reference

Release r08

Note

This product was developed for the purpose of communication. It is intended solely for our clients for integration into their own technical products after careful examination by experienced technical personnel for its suitability for the intended purpose. The product was not developed for or intended for use in any specific customer application. It may have to be adapted to the specific intended modalities of use or even replaced by other components in order to ensure flawless function in the respective areas of application. Performance data (range, power requirements, footprint, etc.) may depend on the operating environment, the area of application, the configuration, and method of control, as well as on other conditions of use; these may deviate from the technical specifications, the Design Guide specifications, or other product documentation. The actual performance characteristics can be determined only by measurements subsequent to integration in the target environment. Variations in the performance data of mass-produced devices may occur due to individual differences between such devices. Product samples were tested in a reference environment for compliance with the legal requirements applicable to the reference environment. No representation is made regarding the compliance with legal, regulatory, or other requirements in other environments. No representation can be made and no warranty can be assumed regarding the suitability of the product for a specific purpose. Telit reserves the right to make changes to the product without prior notice or to replace the product with a successor model. Of course, any changes to the product for which we have entered into a supply agreement with our customers will be made only if, and only to the extent that, such changes can reasonably be expected to be acceptable to our customers. No general commitment will be made regarding periods of availability; these must be subject to individual agreement. All agreements are subject to our Terms and Conditions for Deliveries and Payments.

Trademarks

The Bluetooth[®] word mark and logos are owned by the Bluetooth SIG, Inc.. The NFC word mark and logos are owned by the NFC Forum. Any use of such marks by Telit is under license. Other trademarks and trade names are those of their respective owners.

Table of contents

| | | |
|------|--|----|
| 1 | Introduction | 7 |
| 2 | Commands | 7 |
| A | Accept Incoming Call | 8 |
| &C | DCD Behavior | 8 |
| D | Initiate Bluetooth Link | 8 |
| DL | Initiate Bluetooth Link to Last Dialed Bluetooth Address | 9 |
| &D | DTR Behavior | 9 |
| E | Local Echo | 9 |
| &F | Factory Defaults | 10 |
| H | Disconnect | 10 |
| I | Display Information | 10 |
| O | Return to Online State | 10 |
| Q | Result Messages | 11 |
| &S | DSR Control | 11 |
| S0 | Call Acceptance | 11 |
| S3 | Command Line Termination Character | 11 |
| S4 | Response Formatting Character | 12 |
| S5 | Command Line Editing Character | 12 |
| S301 | Local Device Name | 12 |
| S302 | Class of Device | 13 |
| S305 | Device Role | 16 |
| S307 | Link Supervision Timeout | 16 |
| S308 | Page Scan Interval | 16 |
| S309 | Page Scan Window | 17 |
| S310 | Inquiry Scan Interval | 17 |
| S311 | Inquiry Scan Window | 18 |
| S312 | Name Discovery during Inquiry | 18 |
| S314 | Own Service Profiles (Bit field) | 18 |
| S316 | Scanning Capability | 19 |
| S317 | Page-Scan Repetition Mode | 19 |
| S318 | Local PIN | 20 |
| S323 | Local Baud Rate | 20 |
| S324 | Data Bits | 21 |

| | | |
|-----------|--|----|
| S325 | Stop Bits | 21 |
| S326 | Parity..... | 21 |
| S327 | Variable Baud Rate..... | 22 |
| S329 | Outgoing Default UUID | 22 |
| S330-S332 | Auto Connect Device Address | 23 |
| S334 | Call Retry Timer | 23 |
| S335 | Max Call Retry Counter..... | 24 |
| S337 | Maximum Sniff Interval..... | 24 |
| S338 | Minimum Sniff Interval..... | 24 |
| S339 | Sniff Attempt | 24 |
| S340 | Sniff Timeout..... | 25 |
| S341 | Sniff Mode Supported | 25 |
| S343 | Maximum Output Power..... | 25 |
| S344 | RI Control..... | 26 |
| S345 | Restricted Device Address | 26 |
| S346 | RSSI Value | 26 |
| S347 | Link Quality Value | 27 |
| S348 | Bonding Timeout..... | 27 |
| S350 | Local Service Name for SPP | 27 |
| S401 | Bonded Device List Properties | 28 |
| S402 | Firmware Compatibility Register..... | 28 |
| S403 | Remote Config Port Access Level..... | 29 |
| S404 | Auto Connect Mode | 29 |
| S405 | Non Bondable Mode | 29 |
| S406 | I/O Capabilities..... | 30 |
| S407 | Man in the Middle Protection..... | 30 |
| S408 | SSP Debug Mode | 30 |
| S409 | Power Down..... | 31 |
| S410 | Out of Range Detach | 31 |
| S411 | RSSI Value for Out of Range Detach | 32 |
| S412 | RSSI Poll Time for Out of Range Detach | 32 |
| V | Result Message Format | 33 |
| &V | Display Configuration..... | 33 |
| W | Extended Result Codes..... | 33 |

| | | |
|----------|--|----|
| &W | Store Active Configuration | 33 |
| Z | Load Stored Settings..... | 33 |
| +BBND | Bond With a Bluetooth Device | 34 |
| +BBTA | Set Device to the Bonded Device List with Link Key | 34 |
| +BBTD | Delete Bonding Information | 34 |
| +BBTL | Show Bonded Device List | 34 |
| +BINQ | Start Device Inquiry..... | 35 |
| +BNAME | Get Bluetooth Device Name of Remote Device | 36 |
| +BSRV | Start Service Discovery | 37 |
| +EDUT | Device Under Test Mode | 37 |
| +SSPCONF | Secure Simple Pairing Request..... | 37 |
| +SSPPIN | SSP Passkey Request | 38 |
| | Deprecated commands..... | 38 |
| 3 | Restrictions..... | 38 |
| 4 | Appendix..... | 39 |
| 4.1 | AT Result Codes..... | 39 |
| 4.2 | Extended Result Codes | 39 |
| 5 | History | 42 |

1 Introduction

This document describes the command interface for the BlueMod+B20/BT2.1 featuring software version V3.100 or later. The BlueMod+B20/BT2.1 supports Bluetooth 2.1 with Secure Simple Pairing (SSP).

This document describes commands and registers only. Use cases and examples are described in the *BlueMod+B20/BT2.1 User Guide*.

The BlueMod+B20/BT2.1 has three different operating states. The command state, the online command state and the online data state. In the command state and in the online command state, the BlueMod+B20/BT2.1 can be controlled using the AT-commands described below. In the online data state (data transfer mode) the BlueMod+B20/BT2.1 transmits each character to the remote device via an existing Bluetooth link.

To enter the online command state during an active data connection the following sequence (escape sequence) can be used:

<+><+><+><A><T>

The time interval for the full escape sequence must not exceed 1 second. The escape sequence remains transparent to the remote device.

To activate the detection of the escape sequence the corresponding bit has to be set in the firmware compatibility register (**S402**). The data throughput is decreased significant when using this feature.

2 Commands

Each command line sent from the DTE to the DCE consists of a prefix, a body, and a terminator.

All command lines begin with the prefix **AT** (ASCII 065, 084) or **at** (ASCII 097, 116).

The body is a string of characters in the ASCII range 032-255. Control characters other than <CR> (carriage return; ASCII 013) and <BS> (back space; ASCII 008) in a command line are ignored.

The terminator is <CR>.

There is no distinction between upper-case and lower-case characters. A command line can have a maximum length of 40 characters. It is automatically discarded if the input is longer. Corrections are made using <BS>. Multiple commands on the same command line are not allowed.

If a command line is not terminated with <CR> (carriage return; ASCII 013) within 30 seconds, the command line is discarded.

Commands have the following syntax:

| Syntax | Description |
|-------------------------|--|
| AT<S register>?<CR> | Read the current value of the S register |
| AT<command>=<value><CR> | Write the value of the command |

Responses are sent back to the host and can be any of the following:

| Responses | Description |
|-----------------------|--------------------------------------|
| <CR><LF>OK<CR><LF> | Successful final message |
| <CR><LF>ERROR<CR><LF> | Error message, command not supported |

Each parameter value is stored in the non-volatile memory immediately after executing the command.

The factory-default values of the parameters are marked using the bold letter format.

| | |
|----------|-----------------------------|
| A | Accept Incoming Call |
|----------|-----------------------------|

ATA

This command accepts an incoming call if automatic call acceptance is not set (register S0=0). An incoming call is always signaled with the unsolicited response "RING" or result code "2", even if automatic call acceptance is selected.

| | |
|---------------|---------------------|
| &C | DCD Behavior |
|---------------|---------------------|

AT&C<n>

This command determines the behavior of the DCD control line.

| n | Description |
|----------|---|
| 0 | DCD always ON |
| 1 | DCD ON indicates a Bluetooth connection |
| 2 | DCD follows local DTR |
| 4 | DCD follows remote DCD |

| | |
|----------|--------------------------------|
| D | Initiate Bluetooth Link |
|----------|--------------------------------|

ATD<Bluetooth address> | <bx> [,<UUID | SPP | HID | OPPC > | <service channel>]

This command addresses a Bluetooth device directly via its address or by reference the index bx of the bonded device list entry (b01...bx). If a connection to a Bluetooth 2.0 device is initiated, the PIN must have been set up using **S318** command. When connecting to a Bluetooth 2.1 device a SSP procedure is initiated.

The default UUID from **S329** register or the optional UUID (4-digit hex value) from the command line is used to select the remote service profile. Instead of the UUID

the identifier SPP, HID or OPPC can be used to connect to a SPP, HID or OPP device.

The optional service channel (1 or 2-digit decimal value 1...31) from the command line is used to select the channel of the remote side to connect to. This will only succeed if the service on this channel is supported by the local device.

In case the remote device is not reachable, the authentication fails, the service or the service channel is not available on the remote device the **ATD** command will respond with a "NO CARRIER" message.

Example:

| | |
|-----------------------|---|
| ATD 0080371443AB,1106 | Connect to Bluetooth device 0080371443AB using the remote service profile UUID 1106 |
| ATD 0080371443AB,HID | Connect to Bluetooth device 0080371443AB using the remote service profile HID |
| ATD 0080371443AB,OPPC | Connect to Bluetooth device 0080371443AB using the remote service profile OPP |
| ATD 0080371443AB,1 | Connect to Bluetooth device 0080371443AB to rfcmm channel 1 |
| ATD b01 | Connect to first entry of the bonded device list |

DL Initiate Bluetooth Link to Last Dialed Bluetooth Address

ATDL<Bluetooth address>

This command initiates a Bluetooth link to the last Bluetooth address used with the **ATD** command.

If the **ATD** command was not used prior to the **ATDL** command (e.g. after reset), the command is answered with an ERROR message.

&D DTR Behavior

AT&D<n>

This command determines the behavior of the RTC-IN (DTR in DCE mode) line controlling the Bluetooth connection.

| n | Description |
|---|--|
| 0 | Ignore: Incoming calls will be accepted independently of the DTR status; DTR drop does not disconnect an active connection |
| 1 | On DTR drop go to online command state. Afterwards you can use ATH for hang-up. Leave online command state with ATO command. |
| 2 | Control: Incoming calls will be accepted only when DTR is ON; DTR drop disconnects an active connection |
| 4 | Hang-up: Incoming calls will be accepted independently of the DTR status; DTR drop disconnects an active connection |

E Local Echo

ATE / ATE1

This command sets the local echo in command states on or off.

| Param. | Description |
|--------|---------------------------------|
| ATE | No local echo |
| ATE1 | Local echo on in command states |

&F Factory Defaults

AT&F

The factory-default values will be loaded.

H Disconnect

ATH

This command disconnects an existing Bluetooth connection or disconnects an incoming connection.

The disconnection of an existing Bluetooth connection is only possible in online command state (see setting for AT&D1). After executing the command the firmware automatically performs a transition to command state.

It is possible to disconnect an incoming Bluetooth connection in the state RING. If the incoming Bluetooth connection is disconnected with **ATH**, the firmware automatically performs a transition to command state.

I Display Information

ATI<n>

Read out information from the module. These values cannot be changed.

| Param. | Description |
|--------|---|
| ATI | Show own device name |
| ATI3 | Read out the firmware version |
| ATI4 | Read out the own Bluetooth device address |
| ATI99 | Read out the firmware version |

O Return to Online State

ATO

If the device is in online command state while a connection is active, **ATO** returns the device to data mode (the device will response OK message instead of

CONNECT message). All received data from remote side is lost in command state. See AT&D1 for entering command state during connection.

Q Result Messages

ATQ / ATQ1

This command allows/suppresses result codes and messages.

| Param. | Description |
|--------|--|
| ATQ | Enable result messages after command input |
| ATQ1 | Suppress result messages after command input |

&S DSR Control

AT&S<n>

This command determines the behavior of the RTC-OUT (DSR in DCE mode) control line of the BlueMod+B20/BT2.1.

| n | Description |
|---|---|
| 0 | DSR always ON |
| 1 | DSR ON indicates a Bluetooth connection |
| 2 | DSR follows DTR |
| 3 | DSR follows DCD |
| 4 | DSR follows remote DSR |

S0 Call Acceptance

ATS0=<value>

This command configures the call acceptance.

| Value | Description |
|--------|--|
| 0 | No automatic call acceptance; acceptance of an incoming call is controlled by the data terminal (ATA command after RING) |
| 1 | Immediate call acceptance |
| 2...15 | Call acceptance after n RING messages |

S3 Command Line Termination Character

ATS3=<value>

This command sets the default command line termination character.

To reset the command line termination character to the factory-default, use the **AT&F** command (all parameters will be set to the factory-default). The factory-default setting is 13.

Example:

| | |
|---------|---|
| ATS3=13 | Set command line termination character <CR> |
|---------|---|

Note: The command line termination character is set in decimal format.

S4 Response Formatting Character

ATS4=<value>

This command sets the default response formatting character.

To reset the response formatting character to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default). The factory-default setting is 10.

Example:

| | |
|---------|--|
| ATS4=10 | Set response formatting character <LF> |
|---------|--|

Note: The response formatting character is set in decimal format.

S5 Command Line Editing Character

ATS5=<value>

This command sets the default command line editing character .

To reset the BS character to the factory-default, use the **AT&F** command (all parameters will be set to the factory-default). The factory-default setting is 8.

Example:

| | |
|--------|--|
| ATS5=8 | Set command line editing character to <BS> |
|--------|--|

Note: The command line editing character is set in decimal format.

S301 Local Device Name

ATS301=<name>

This command allows the modification of the local device name. The device name is shown on a remote Bluetooth device during device/service discovery. It is limited to 31 characters, the output of the string has to match this length.

The device name can contain a format string to include the device's own address or parts of it in the name.

Format: "%[<s>][<d>a"

| | |
|-----|--|
| "%" | Identifier start format string |
| <s> | Character separator on byte order (optional) |
| <d> | Number (1-12) of digits included in device name (optional, default is 4) |
| "a" | Identifier end format string |

Examples: Device address = "0123456789AB"

| | |
|--------------------------|--|
| ATS301=BlueMod+B20 %:4a | Display on remote end: BlueMod+B20 89:AB |
| ATS301=BlueMod+B20 %4a | Display on remote end: BlueMod+B20 89AB |
| ATS301=BlueMod+B20 %:3a | Display on remote end: BlueMod+B20 9:AB |
| ATS301=BlueMod+B20 %3a | Display on remote end: BlueMod+B20 9AB |
| ATS301=BlueMod+B20 %:12a | Display on remote end: BlueMod+B20 01:23:45:67:89:AB |

*Note: This command has to be executed with a "=" sign, if a blank is used between **ATS301** and name an **ERROR** is the feedback. This is because blanks are allowed for a device name, e.g. "B20 device".*

| | |
|-------------|------------------------|
| S302 | Class of Device |
|-------------|------------------------|

ATS302=<value (hex)>

This command allows the manipulation of the Bluetooth class of device (CoD).

Note: Changing the class of device affects profile-specific requirements and may influence interoperability. Change this only if you are certain of all side effects.

The CoD consists of 3 octets (24 bits). Bits 23 through 13 define the service class, bits 12 through 8 define the major device class, and bits 7 through 2 define the minor device class. Bits 1 and 0 are reserved and must always be set to 0.

The **service class** field is a bit field; no bit, one bit or several bits can be set, depending on the profile requirements.

Service classes:

| Bit | Description |
|-----|---|
| 13 | Limited discoverable mode |
| 14 | Reserved |
| 15 | Reserved |
| 16 | Positioning (location identification) |
| 17 | Networking (LAN, ad-hoc, ...) |
| 18 | Rendering (printing, speaker, ...) |
| 19 | Capturing (scanner, microphone, ...) |
| 20 | Object transfer (v-inbox, v-folder, ...) |
| 21 | Audio (speaker, microphone, headset service, ...) |
| 22 | Telephony (cordless telephony, modem, headset service, ...) |
| 23 | Information (Web server, WAP server, ...) |

The **major device** class field represents the highest level of granularity for defining a Bluetooth device. The main function of a device is used to determine the major device class setting (bits 12 through 8 in the CoD).

Major device class:

| Bit | 12 | 11 | 10 | 9 | 8 | Description |
|-----|----|----|----|---|---|---|
| | 0 | 0 | 0 | 0 | 1 | Computer (desktop, notebook, PDA, organizer, ...) |
| | 0 | 0 | 0 | 1 | 0 | Phone (cellular, cordless, payphone, modem, ...) |
| | 0 | 0 | 0 | 1 | 1 | LAN/network access point |
| | 0 | 0 | 1 | 0 | 0 | Audio/video (headset, speaker, stereo, video display, VCR, ...) |
| | 0 | 0 | 1 | 0 | 1 | Peripheral (mouse, joystick, keyboards, ...) |
| | 0 | 0 | 1 | 1 | 0 | Imaging (printing, scanner, camera, display, ...) |
| | 0 | 0 | 1 | 1 | 1 | Wearable |
| | 0 | 1 | 0 | 0 | 0 | Toy |
| | 0 | 1 | 0 | 0 | 1 | Health |
| | 1 | 1 | 1 | 1 | 1 | Uncategorized, specific device code not specified |

The **minor device** class field (bits 7 through 2 in the CoD) can be interpreted only in the context of the major device class (but independently of the service class field). The meaning of the bits may therefore change depending on the major device class.

Minor device class values for the “Computer” major device class:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | Description |
|-----|---|---|---|---|---|---|--|
| | 0 | 0 | 0 | 0 | 0 | 0 | Uncategorized, specific device code not assigned |
| | 0 | 0 | 0 | 0 | 0 | 1 | Desktop workstation |
| | 0 | 0 | 0 | 0 | 1 | 0 | Server-class computer |
| | 0 | 0 | 0 | 0 | 1 | 1 | Laptop |
| | 0 | 0 | 0 | 1 | 0 | 0 | Handheld PC/PDA (clam shell) |
| | 0 | 0 | 0 | 1 | 0 | 1 | Palm-sized PC/PDA |
| | 0 | 0 | 0 | 1 | 1 | 0 | Wearable computer (watch-sized) |

Minor device class values for the “Phone” major device class:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | Description |
|-----|---|---|---|---|---|---|--|
| | 0 | 0 | 0 | 0 | 0 | 0 | Uncategorized, specific device code not assigned |
| | 0 | 0 | 0 | 0 | 0 | 1 | Cellular |
| | 0 | 0 | 0 | 0 | 1 | 0 | Cordless |
| | 0 | 0 | 0 | 0 | 1 | 1 | Smart phone |
| | 0 | 0 | 0 | 1 | 0 | 0 | Wired modem or voice gateway |
| | 0 | 0 | 0 | 1 | 0 | 1 | Common ISDN access |

Minor device class values for the “Peripheral” major device class:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | Description |
|-----|---|---|---|---|---|---|------------------------------------|
| | 0 | 0 | 0 | 0 | 0 | 0 | Not keyboard / not pointing device |
| | 0 | 1 | 0 | 0 | 0 | 0 | Keyboard |
| | 1 | 0 | 0 | 0 | 0 | 0 | Pointing device |
| | 1 | 1 | 0 | 0 | 0 | 0 | Combo keyboard / pointing device |

Minor device class values for the “Health” major device class:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | Description |
|-----|---|---|---|---|---|---|--------------------------|
| | 0 | 0 | 0 | 0 | 0 | 0 | Undefined |
| | 0 | 0 | 0 | 0 | 0 | 1 | Blood pressure monitor |
| | 0 | 0 | 0 | 0 | 1 | 0 | Thermometer |
| | 0 | 0 | 0 | 0 | 1 | 1 | Weighing scale |
| | 0 | 0 | 0 | 1 | 0 | 0 | Glucose meter |
| | 0 | 0 | 0 | 1 | 0 | 1 | Pulse oximeter |
| | 0 | 0 | 0 | 1 | 1 | 0 | Heart/pulse rate monitor |
| | 0 | 0 | 0 | 1 | 1 | 1 | Health data display |

For the description of other minor device classes, refer to the Bluetooth specification.

Examples:

| | |
|-------------------|---|
| ATS302=0x00001F00 | Uncategorized, specific device code not specified |
| ATS302=0x00000210 | Wired modem |
| ATS302=0x00000540 | HID keyboard |
| ATS302=0x0000090C | Weighing scale |

| | |
|-------------|--------------------|
| S305 | Device Role |
|-------------|--------------------|

ATS305=<value>

This command sets the device role for all connections.

| Value | Description |
|-------|------------------|
| 0 | Master preferred |
| 1 | Slave preferred |
| 2 | Don't care |

To reset the device role to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|----------|---------------------------------|
| ATS305=2 | Set device role to "don't care" |
|----------|---------------------------------|

| | |
|-------------|---------------------------------|
| S307 | Link Supervision Timeout |
|-------------|---------------------------------|

ATS307=<value>

This command sets the link supervision timeout in seconds. The factory-default setting is 20. The valid range is 1 - 40.

The link supervision timeout parameter is used by the master or slave Bluetooth device to monitor link loss. If, for any reason, no base band packets are received on an active connection for a duration longer than the link supervision timeout, the connection is disconnected. This value is used on all connections. However only the master device of a Bluetooth connection can set this timeout value for a connection.

To reset the link supervision timeout to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|-----------|---|
| ATS307=20 | Set link supervision timeout to 20 sec. |
|-----------|---|

| | |
|-------------|---------------------------|
| S308 | Page Scan Interval |
|-------------|---------------------------|

ATS308=<value>

This command sets the page scan interval. The factory-default setting is 2048. Valid range is from 18 to 4096, only even values are allowed.

| Value | Description |
|-------------|--|
| n=18...4096 | Page scan interval for n*0.625 ms (n is a decimal value) |
| 2048 | Page scan interval set to 1.28 s |

To reset the page scan interval to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|-----------|--|
| ATS308=20 | Set current value of the page scan interval to 12.5 ms |
|-----------|--|

Note: Setting the page scan interval to values below the default significantly increases the power consumption.

| | |
|-------------|-------------------------|
| S309 | Page Scan Window |
|-------------|-------------------------|

ATS309=<value>

This command sets the page scan window value. The factory default setting is 18. Valid range is from 17 to 4096.

To reset the page scan window to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| Value | Description |
|-------------|--|
| n=17...4096 | Page scan window for n*0.625 ms (n is a decimal value) |
| 18 | Page scan window set to 11.25 ms |

Example:

| | |
|-----------|--|
| ATS309=20 | Set current value of the page scan window to 12.5 ms |
|-----------|--|

Note: The page scan window has to be less or equal the page scan interval.

| | |
|-------------|------------------------------|
| S310 | Inquiry Scan Interval |
|-------------|------------------------------|

ATS310=<value>

This command sets the inquiry scan interval. The factory default setting is 2048. Valid range is from 18 to 4096, only even values are allowed.

To reset the inquiry scan interval to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| Value | Description |
|-------------|---|
| n=18...4096 | Inquiry scan interval for n*0.625 ms (n is a decimal value) |
| 2048 | Inquiry scan interval set to 1.28 s |

Example:

| | |
|-----------|---|
| ATS310=20 | Set current value of the inquiry scan interval to 12.5 ms |
|-----------|---|

Note: Setting the inquiry scan interval to values below the default significantly increases the power consumption.

| | |
|-------------|----------------------------|
| S311 | Inquiry Scan Window |
|-------------|----------------------------|

ATS311=<value>

This command sets the inquiry scan window. The factory default setting is 18.

Valid range is from 17 to 4096.

To reset the inquiry scan window to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| Value | Description |
|-------------|---|
| n=17...4096 | Inquiry scan window for n*0.625 ms (n is a decimal value) |
| 18 | Inquiry scan window set to 11.25 ms |

Example:

| | |
|-----------|---|
| ATS311=20 | Set current value of the inquiry scan window to 12.5 ms |
|-----------|---|

| | |
|-------------|--------------------------------------|
| S312 | Name Discovery during Inquiry |
|-------------|--------------------------------------|

ATS312=<value>

This parameter controls the name discovery during an inquiry using **AT+BINQ** command. The name discovery works for a maximum of 40 different Bluetooth devices.

| Value | Description |
|----------|-----------------------------------|
| 0 | Name discovery during inquiry off |
| 1 | Name discovery during inquiry on |

| | |
|-------------|---|
| S314 | Own Service Profiles (Bit field) |
|-------------|---|

ATS314=<value>

This command defines the services the BlueMod+B20/BT2.1 reports to a remote Bluetooth device during a service discovery sequence. Two multiple profiles at the same time are supported and can be selected by combining the profile values (AND operation).

The service class bit of **S302** is affected by **S314**. Setting an OBEX service in **S314** (OBEX Push, OBEX FTP) sets the service class bit in **S302** (bit 20, Object transfer) automatically. Setting non OBEX services removes the service class bit (bit 20, Object transfer) in **S302** again.

| Value | Description |
|-------|-----------------------|
| 0x01 | SPP (UUID 1101) |
| 0x02 | DUN (UUID 1103) |
| 0x10 | HID (UUID 1124) |
| 0x80 | OBEX Push (UUID 1105) |
| 0x100 | OBEX FTP (UUID 1106) |

Example:

| | |
|--------------|----------------------|
| ATS314=0x100 | Set OBEX FTP profile |
|--------------|----------------------|

Note: The profile specific higher protocols (DUN AT, PPP, OBEX), must be implemented on the device host.

S316 Scanning Capability

ATS316=<value>

This command controls the visibility (inquiry) of the device and its ability to accept connections (paging). If set to “0” all paging/inquiry requests from other Bluetooth devices will be ignored, and the RF receiver of the BlueMod+B20/BT2.1 is disabled.

| Value | Description |
|-------|--|
| 0 | Page scan and inquiry scan are disabled; the BlueMod+B20/BT2.1 is not connectable and not discoverable |
| 1 | Inquiry scan is enabled; the BlueMod+B20/BT2.1 is discoverable, but not connectable |
| 2 | Page scan is enabled; the BlueMod+B20/BT2.1 is connectable, but not discoverable |
| 3 | Page scan and inquiry scan are enabled; the BlueMod+B20/BT2.1 is connectable and discoverable |

S317 Page-Scan Repetition Mode

ATS317=<value>

This parameter gives the interval between successive page scans starting at the paged/remote device, and hence defines how long it will take to connect. The parameter must be aligned to the remote page scan interval (see **S308** register in case the remote device is a BlueMod+B20/BT2.1).

Possible values according to the Bluetooth base band specification are:

| Value | Description |
|-------|---|
| 0 | R0 continuous scan, page scan interval <= 1.28 s and = page scan window |
| 1 | R1 page scan interval <= 1.28 s |
| 2 | R2 page scan interval <= 2.56 s |

Continuous scanning (on both devices) decreases the connect time down to about 200 ms:

- R0: about 200 ms
- R1: about 2.2 s
- R2: about 3.5 s

Note: The page scan window and interval must be set in conformance to the page-scan repetition mode.

| | |
|-------------|------------------|
| S318 | Local PIN |
|-------------|------------------|

ATS318=<PIN>

This command sets the PIN for the device. The PIN is used for legacy pairing (pairing to a Bluetooth 2.0 device) only. It is not used in case of SSP.

The PIN has a maximum length of 16 alphanumeric characters; the factory-default is "0000".

After a bonding has taken place (PIN successful exchanged), Bluetooth links can be established between the bonded devices independently of the settings and of the PIN.

To reset the PIN to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|-------------|-----------------|
| ATS318=1234 | Set PIN to 1234 |
|-------------|-----------------|

Note: Prefer a PIN composed of only decimal digits. Do not assume that a remote device with limited user-interface capabilities supports alphabetic characters.

| | |
|-------------|------------------------|
| S323 | Local Baud Rate |
|-------------|------------------------|

ATS323=<value>

This command determines the baud rate for the UART.

| Value | Description |
|---------------|-------------|
| 1200 | 1,200 bps |
| 2400 | 2,400 bps |
| 4800 | 4,800 bps |
| 9600 | 9,600 bps |
| 19200 | 19,200 bps |
| 38400 | 38,400 bps |
| 57600 | 57,600 bps |
| 115200 | 115,200 bps |
| 230400 | 230,400 bps |
| 460800 | 460,800 bps |
| 921600 | 921,600 bps |

Example:

| | |
|-------------|----------------------------|
| ATS323=9600 | Set baud rate to 9,600 bps |
|-------------|----------------------------|

S324 Data Bits

ATS324=<value>

This command defines the number of data bits (asynchronous characters).

| Value | Description |
|----------|-----------------|
| 8 | Use 8 data bits |

Note: This product supports 8 data bits only!

S325 Stop Bits

ATS325=<value>

This command defines the number of stop bits of asynchronous character.

| Value | Description |
|----------|---------------|
| 1 | One stop bit |
| 2 | Two stop bits |

S326 Parity

ATS326=<value>

This command defines the parity of asynchronous characters.

| Value | Description |
|-------|-------------|
| 0 | No parity |
| 1 | Odd parity |
| 2 | Even parity |

S327 Variable Baud Rate

ATS327=<value>

This command configures the baud rate of the UART interface within the range of 1,200 - 921,600 bps. All values that are a multiple of 244.141 can be set.

Values that are not exactly a multiple of 244.141 will be recalculated internally. So if the value of this command is set to 10,000, $41 \times 244.141 = 10009$ will be set.

Be careful in use with this command, if set to a value not supported by your remote device the user PSKEY's have to be reset!

| Value | Description |
|---------------|---|
| 1200-921600 | All multiples of 244.141 within this range are possible |
| 115200 | 115,234 bps |

*Note: When **S327** command is set, **S323** command will show the same value. When **S323** command is set, **S327** command will show the same value. So both commands are consistent.*

S329 Outgoing Default UUID

ATS329=<value>

This command sets the default UUID for outgoing call. The default setting is 0x1101. The module will use this UUID to search the service on the remote device.

| Value | Description |
|---------------|--------------------|
| 0x1101 | Serial port (SPP) |
| 0x1103 | Dial-up networking |
| 0x1105 | OBEX object push |
| 0x1106 | OBEX file transfer |

To reset the default UUID to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|---------------|------------|
| ATS329=0x1103 | Set to DUN |
|---------------|------------|

| | |
|------------------|------------------------------------|
| S330-S332 | Auto Connect Device Address |
|------------------|------------------------------------|

ATS330=<Bluetooth address>[,<UUID> | <service channel>]
 ATS331=<Bluetooth address>[,<UUID> | <service channel>]
 ATS332=<Bluetooth address>[,<UUID> | <service channel>]

This command sets up up to 3 Bluetooth addresses of remote Bluetooth devices that should be connected using an automatic link setup if auto connect mode is enabled in **S404** register. It contains a complete dial string, with an optional UUID (4-digit hex value) or service channel (1 or 2-digit decimal value 1...31). In the default configuration no automatic link setup will be performed.

If auto connect mode is enabled in **S404** register the module tries to connect to the Bluetooth address from **S330** register with the specified UUID or service channel. If no UUID or service channel is stored, the default UUID from **S329** register is used. If **S330** does not contain a Bluetooth address or if the connection setup fails, the device tries to set up a connection to the Bluetooth address from **S331** register. If **S331** does not contain a Bluetooth address or if the connection setup fails, the device tries to set up a connection to the Bluetooth address from **S332** register. If **S332** does not contain a Bluetooth address or if the connection setup fails a call retry starts after a time period from **S334** register. This connection retry has a maximum counter set in **S335** register. It begins with the Bluetooth address from **S330** register again.

ATS330=0, ATS331=0, ATS332=0 deletes the stored dial string.

Example:

| | |
|--------------------------|---|
| ATS330=0123456789AB | Automatic link setup to Bluetooth device 0123456789AB |
| ATS330=0123456789AB,1103 | Automatic link setup to Bluetooth device 0123456789AB to UUID 1103 |
| ATS330=0123456789AB,2 | Automatic link setup to Bluetooth device 0123456789AB to rfcomm channel 2 |

*Note: For an automatic link setup the register **S404** has to be set to 1 and at least one of the registers **S330-S332** has to contain a dial string.*

| | |
|-------------|-------------------------|
| S334 | Call Retry Timer |
|-------------|-------------------------|

ATS334=<value>

This command defines the timeout (in seconds) before making the next call attempt by using auto connect mode. The default setting is 0, no call retry attempt will be performed. The maximum value is 255.

| | |
|-------------|-------------------------------|
| S335 | Max Call Retry Counter |
|-------------|-------------------------------|

ATS335=<value>

This command defines the max call retry counter by using auto connect mode. The default setting is 0, call retry will be performed forever. The maximum value is 255.

| Value | Description |
|-------|---------------|
| 0 | Retry forever |
| 1 | Retry 1 time |
| 5 | Retry 5 times |

| | |
|-------------|-------------------------------|
| S337 | Maximum Sniff Interval |
|-------------|-------------------------------|

ATS337?

Read out current value of the maximum sniff interval (in ms) from module. This value is read-only. It depends on the settings of the **S341** command. The default value is 250 ms.

To reset the maximum sniff interval to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| | |
|-------------|-------------------------------|
| S338 | Minimum Sniff Interval |
|-------------|-------------------------------|

ATS338?

Read out current value of the minimum sniff interval (in ms) from module. This value is read-only. It depends on the settings of the **S341** command. The default value is 20 ms.

To reset the minimum sniff interval to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| | |
|-------------|----------------------|
| S339 | Sniff Attempt |
|-------------|----------------------|

ATS339?

Read out current value of the sniff attempts from module. This value is read-only. It depends on the settings of the **S341** command. The default value is 1 attempt.

To reset the sniff attempts to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| | |
|-------------|----------------------|
| S340 | Sniff Timeout |
|-------------|----------------------|

ATS340?

Read out current value of the sniff timeout from the module. This value is read-only. It depends on the settings of the **S341** command. The default value is 8 time slots.

To reset the sniff timeout to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

| | |
|-------------|-----------------------------|
| S341 | Sniff Mode Supported |
|-------------|-----------------------------|

ATS341=<value>

This command sets the supported sniff mode. The factory default setting is 1.

Sniffing is used to reduce power consumption during an active Bluetooth connection. When a Bluetooth link is in sniff mode both connected devices can enter a power-saving state for a short time interval. The length of this interval is called “sniff interval” and is negotiated between the connected devices. The maximum and minimum acceptable values for the sniff interval can be set using the appropriate AT commands. The sniff interval value has an impact on the propagation delay and maximum throughput on the Bluetooth link. Note that in order to enter sniff mode, both devices need to support sniff mode.

| Value | Description |
|-------|--------------------------------|
| 0 | No sniff support |
| 1 | Active sniff support – 250 ms |
| 2 | Passive sniff support |
| 3 | Active sniff support – 500 ms |
| 4 | Active sniff support – 1000 ms |

If active sniff support is enabled, the device tries to setup a sniff interval with the value mentioned in the table above.

Passive sniff support means that the device accepts sniff requests from the remote device with an interval negotiated with the remote device.

Example:

| | |
|----------|------------------------------|
| ATS341=0 | Disable sniff support |
| ATS341=2 | Enable passive sniff support |

| | |
|-------------|-----------------------------|
| S343 | Maximum Output Power |
|-------------|-----------------------------|

ATS343=<value>

This command sets the maximum output power for the device.

| Value | Description |
|---------|--|
| -128 | Use factory default maximum output power |
| -24...4 | Maximum output power in dBm |

All other values in the range of -128 to 127 could be set in the register as well, but the equal or next lower value from the power table will be set internally. Furthermore the value will be set to a value amongst minimum and maximum output power value of the device.

Example:

| | |
|------------|---|
| ATS343=-15 | The maximum output power will be set to -16 dBm |
|------------|---|

S344 RI Control

ATS344=<value>

This command configures the behavior of the RI signal.

| Value | Description |
|-------|---|
| 0 | RI indicates an incoming Bluetooth link request |
| 1 | RI follows the remote RI line status |

S345 Restricted Device Address

ATS345=<Bluetooth address>

This command configures a Bluetooth address which is restricted for incoming connection requests to BlueMod+B20/BT2.1. The default value is 000000000000, no device is restricted. If a valid Bluetooth address is stored, the according device is restricted and the incoming connection request is refused. ATS345=0 deletes the restriction.

S346 RSSI Value

ATS346?

Read out current absolute receive signal strength (RSSI) value in dBm of an active link. This value is read-only.

Most common values are in the range of -20 dBm to -80 dBm. The higher the value the better the receive signal. In unconnected state the value 127 is shown.

To get the current RSSI value of an active link switch into online command mode either using DTR drop or escape sequence and enter ATS346? command.

| | |
|-------------|---------------------------|
| S347 | Link Quality Value |
|-------------|---------------------------|

ATS347?

Read out current link quality value of an ACL connection. This value is read-only. The range of the value is from 0 to 255. ATS347 returns a number that is directly equivalent to bit error rate (BER).

Each bit distance between 255 and 215 represents 0.0025% BER:

| Value | Description |
|-------|-------------|
| 255 | 0.0000% BER |
| 254 | 0.0025% BER |
| ... | |
| 215 | 0.1000% BER |

Each bit distance between 214 and 90 represents 0.08% BER.

Each bit distance between 89 and 0 represents 0.08% BER.

In general, a link with a BER between 0% and 0.1% is workable. Trying to run a link with a BER above 1% will give poor results.

| | |
|-------------|------------------------|
| S348 | Bonding Timeout |
|-------------|------------------------|

ATS348=<value>

This command defines the bonding timeout in seconds. The factory-default setting is 30. The valid range is 1 - 30.

The bonding timeout parameter is used to control the time for the bonding procedure. If, for any reason, the bonding procedure exceeds the specified value, the bonding fails. This value is used with all connections that require bonding. However only the master device of a Bluetooth connection can set this timeout value for a connection.

To reset the bonding timeout to the factory-default, use the **AT&F** command (Attention: All parameters will be set back to the factory-default).

Example:

| | |
|-----------|-----------------------------|
| ATS348=20 | Set bonding timeout to 20 s |
|-----------|-----------------------------|

| | |
|-------------|-----------------------------------|
| S350 | Local Service Name for SPP |
|-------------|-----------------------------------|

ATS350=<name>

This command allows the modification of the local service name for the serial port of the BlueMod+B20/BT2.1. The service name is shown on a remote Bluetooth device during a service discovery. It is limited to 15 characters.

Example:

| | |
|--------------------|----------------------------|
| ATS350= SPP | Display on remote end: SPP |
|--------------------|----------------------------|

*Note: This command has to be executed with a "=" sign, if a blank is used between **ATS350** and name an **ERROR** is the feedback. This is because blanks are allowed for a service name, e.g. "serial port".*

S401 Bonded Device List Properties

ATS401=<value>

This command controls the storing behavior of the bonded device list.

| Value | Description |
|-------|---|
| 0 | Authenticated devices are not stored on the bonded device list, existing entries are unaffected |
| 1 | Authenticated devices are stored on the bonded device list |

S402 Firmware Compatibility Register

ATS402=<value>

This command controls the compatibility of the firmware to prior versions. The register contains 16 bits, the value is shown as hex value.

Bit 1 controls the storing behavior of the parameter set.

| Bit 1 | Function |
|-------|---|
| 0 | All values are stored in volatile memory only. To store persistently use the AT&W command |
| 1 | All values are stored in non-volatile memory automatically |

Bit 2 controls the escape sequence detection in connected state.

| Bit 2 | Function |
|-------|---|
| 0 | Escape sequence detection switched off |
| 1 | Escape sequence detection switched on (limited data throughput) |

Note: The escape sequence detection applies to SPP and OPP profile only.

All other bits are reserved and cannot be modified via AT commands.

Examples:

| | |
|-----------------------|--|
| ATS402= 0x0001 | Auto save to non-volatile memory is switched on and escape sequence detection is switched off |
| ATS402=0x0000 | Auto save to non-volatile memory is switched off and escape sequence detection is switched off |
| ATS402=0x0003 | Auto save to non-volatile memory is switched on and |

| | |
|--|--|
| | escape sequence detection is switched on |
|--|--|

| | |
|-------------|--|
| S403 | Remote Config Port Access Level |
|-------------|--|

ATS403=<value>

This command defines the accessibility and visibility of the Bluetooth remote configuration port.

| Value | Description |
|-------|---|
| 0 | Config port is neither accessible nor visible |
| 1 | Config port is accessible but not visible |
| 2 | Config port is accessible and visible |

| | |
|-------------|--------------------------|
| S404 | Auto Connect Mode |
|-------------|--------------------------|

ATS404=<value>

This command controls the auto connect behavior of the device.

| Value | Description |
|-------|---|
| 0 | Auto connect off |
| 1 | Auto connect on (at least one of the registers S330-S332 has to be set, otherwise no auto connect could be done) |

Once the auto connect mode is activated it can be switched off again after resetting the device and immediately (before the connection is established) setting the **S404** register back to "0". If possible it is recommended to power-off the remote device(s) before this operation.

Note: Changes becomes active after resetting the device.

| | |
|-------------|--------------------------|
| S405 | Non Bondable Mode |
|-------------|--------------------------|

ATS405=<value>

This command controls the bonding behavior of the device. If a remote device initiates a pairing and the non-bondable mode is active, the device refuses the pairing and the connection is terminated.

| Value | Description |
|-------|----------------------------|
| 0 | Non bondable mode disabled |
| 1 | Non bondable mode enabled |

S406 I/O Capabilities

ATS406=<value>

This command sets the input and output capabilities of the device used for SSP.

| Value | Description |
|-------|--------------------|
| 0 | Display only |
| 1 | Display Yes/No |
| 2 | Keyboard only |
| 3 | No input no output |

S407 Man in the Middle Protection

ATS407=<value>

This command controls the man in the middle (MITM) protection of the device during SSP. It has to be set in context with **S406** command. In SSP there are scenarios where MITM protection is not possible (see *BlueMod+B20/BT2.1 User Guide*).

| Value | Description |
|-------|---------------------------------------|
| 0 | Man in the middle protection disabled |
| 1 | Man in the middle protection enabled |

In case the user choose a scenario where MITM protection is not allowed but one of the communication devices is configured to **S407=1** (MITM protection enabled), the pairing is refused.

Possible combinations of I/O capabilities and the possibility of MITM protection are described in the *BlueMod+B20/BT2.1 User Guide*.

S408 SSP Debug Mode

ATS408=<value>

This command allows to enable the SSP debug mode of the device. This mode is required to trace the SSP Bluetooth connection by using a sniffer.

| Value | Description |
|-------|--------------------|
| 0 | SSP Debug mode off |
| 1 | SSP Debug mode on |

Note: SSP debug mode is for tracing purposes only and shall be deactivated for normal operation. Otherwise the connection may be unsecure.

| | |
|------|------------|
| S409 | Power Down |
|------|------------|

ATS409=<value>

This command controls the power down functionality of the device. If active, the device enters a power down state 250 ms after the DTR line is set inactive (high).

| Value | Description |
|-------|---------------------|
| 0 | Power down disabled |
| 1 | Power down enabled |

The power down state is interrupted by:

- An incoming connection
- Setting DTR line active (low)
- Activity on RX UART line, e.g. sending a character on the UART interface (the device stays awake for 250 ms after a character was sent)

For more information regarding the different power down states refer to the *BlueMod+B20/BT2.1 User Guide*.

Note: It is recommended to use the DTR line to control the power down behavior. Using the UART by sending characters as a "wake up" event may result in loss of data.

| | |
|------|---------------------|
| S410 | Out of Range Detach |
|------|---------------------|

ATS410=<value>

This command controls the "Out of Range Detach" feature of the device. If enabled and the device moves out of range (RSSI weaker than specified in **S411**) the connection is detached automatically.

| Value | Description |
|-------|------------------------------|
| 0 | Out of range detach disabled |
| 1 | Out of range detach enabled |

S411 RSSI Value for Out of Range Detach

ATS411=<value>

This command defines the RSSI value in dB for the “Out of Range Detach” feature. The default value is -80 dB. This value applies only if “Out of Range Detach” feature is enabled in **S410**.

| Value | Description |
|-----------|--------------------------|
| -127...-1 | RSSI value -127...-1 dBm |

Examples:

| | |
|------------|--|
| ATS411=-80 | Set RSSI value for out of range detach to -80 dB |
| ATS411=-75 | Set RSSI value for out of range detach to -75 dB |

S412 RSSI Poll Time for Out of Range Detach

ATS412=<value>

This command defines the poll time in milliseconds for measuring the RSSI value for the “Out of Range Detach” feature. The default value is 3000 milliseconds. This value applies only if “Out of Range Detach” feature is enabled in **S410**.

The application compares the mean value of the last 3 measured RSSI values to the value set in **S411**.

| Value | Description |
|-----------|-----------------------------|
| 1...10000 | RSSI poll time 1...10000 ms |

Examples:

| | |
|-------------|-----------------------------------|
| ATS412=3000 | Set RSSI poll time to 3 seconds |
| ATS412=2500 | Set RSSI poll time to 2.5 seconds |

For more information regarding the “Out of Range Detach” feature refer to the *BlueMod+B20/BT2.1 User Guide*.

| | |
|---|-----------------------|
| V | Result Message Format |
|---|-----------------------|

ATV / ATV1

This command determines the format of the result messages.

| Param. | Description |
|--------|--|
| ATV | Result message is presented numerically (followed by <CR>) |
| ATV1 | Result message is presented as text |

| | |
|----|-----------------------|
| &V | Display Configuration |
|----|-----------------------|

AT&V

This command displays the current configuration of the BlueMod+B20/BT2.1.

| | |
|---|-----------------------|
| W | Extended Result Codes |
|---|-----------------------|

ATW / ATW1

This command enables/disables extended result codes (see chapters 4.1 AT Result Codes and 0

Extended Result Codes).

| Param. | Description |
|--------|---|
| ATW | Result message is presented without extended result codes |
| ATW1 | Result message is presented with extended result codes |

| | |
|----|----------------------------|
| &W | Store Active Configuration |
|----|----------------------------|

AT&W

This command stores the active configuration (parameter set) in non-volatile memory.

| | |
|---|----------------------|
| Z | Load Stored Settings |
|---|----------------------|

ATZ

This command loads the stored configuration (parameter set) from non-volatile memory.

Note: This command must be the last command in the AT command line.

| | |
|--------------|-------------------------------------|
| +BBND | Bond With a Bluetooth Device |
|--------------|-------------------------------------|

AT+BBND=<Bluetooth address>

This command initiates a bonding process with a remote Bluetooth device.

If the bonding is successful, the BlueMod+B20/BT2.1 returns "SUCCESS", otherwise "FAILED".

After a successful bonding the device is stored on the bonded device list (see +BBTL command).

Example:

| | |
|----------------------|--|
| AT+BBND=010203040506 | Bond with device with Bluetooth address 010203040506 |
|----------------------|--|

| | |
|--------------|---|
| +BBTA | Set Device to the Bonded Device List with Link Key |
|--------------|---|

AT+BBTA=<Bluetooth address>,<link key>

This command sets a device with a given link key to the bonded device list (see +BBTL command).

The link key is a 32-digit hex value (0...F) like shown in the example below.

Example:

| |
|--|
| AT+BBTA=001025011111,00112233445566778899AABBCCDDEEFF → Bond with device with Bluetooth address 001025011111 using link key 00112233445566778899AABBCCDDEEFF |
|--|

| | |
|--------------|-----------------------------------|
| +BBTD | Delete Bonding Information |
|--------------|-----------------------------------|

AT+BBTD=<Bluetooth address>

This command deletes the bonding information stored by the BlueMod+B20/BT2.1.

Example:

| | |
|----------------------|--|
| AT+BBTD=* | Delete whole bonding table |
| AT+BBTD=010203040506 | Delete bonded device with Bluetooth address 010203040506 |

| | |
|--------------|--------------------------------|
| +BBTL | Show Bonded Device List |
|--------------|--------------------------------|

AT+BBTL

This command shows information about the devices bonded with the BlueMod+B20/BT2.1.

The maximum capacity of this list depends on the implementation in the firmware, actual maximum is 8 entries. If the bonded device list is full and another device is bonded, the least recently used device will be overwritten by the new one.

Example:

| | |
|---------|-------------------------|
| AT+BBTL | b01: 00038949AFAC OK |
|---------|-------------------------|

+BINQ Start Device Inquiry

AT+BINQ [class value][,EIR]

This command starts a device inquiry. In the result it lists the found Bluetooth devices with their Bluetooth address, class code and RSSI value. For a detailed description about the class code see **S302** parameter. The RSSI value represents the absolute receive signal strength of the found Bluetooth device.

In the example below “0080250000A7” represents the Bluetooth address, “1F00” the class code and “rssi -68” the RSSI value in dBm.

Example:

| Command | Response |
|---------|----------------------------------|
| AT+BINQ | 0080250000A7 1F00 rssi -68 OK |

The inquiry time is 10 seconds. During this time several inquiry attempts are made. If a found Bluetooth device answers to each inquiry attempt it can happen that the device occurs more than one time in the list. The number of found Bluetooth devices is limited by the 10 second timeout.

When no class value is given, the device searches for all class codes. If the class value is set, only devices with those bits set in their class of device will be reported. This filter can be made as specific or as general as necessary. Please note that the filter reports devices that have a minimum of the specified bits set, however it is possible that a device also has other bits set in its class of device field. In that case that device will be reported back.

To discover all devices with major device class set to audio/video, set the class value to 0x400. This will result in devices with, class of device set to 0x200404 and 0x200408 to be reported. If, however, we want to limit the device search even further and only discover devices with their class of device set to headset, for example, the class of device field should be set to 0x200404.

Example:

| | |
|------------------|---|
| AT+BINQ | 0080250000A7 1F00 rssi -68 008025084FBB 1F18 rssi -73 008025084FBA 1F98 rssi -71 0009DD502C46 2010C rssi -83 010203040506 220404 rssi -81 OK |
| AT+BINQ 0x1F00 | 0080250000A7 1F00 rssi -66 008025084FBB 1F18 rssi -73 008025084FBA 1F98 rssi -71 OK |
| AT+BINQ 0x200400 | 010203040506 220404 rssi -81 OK |

The optional identifier EIR sets the inquiry mode to extended inquiry response. The result list can handle EIR of remote devices.

Note: Due to an internal memory problem of CSR the result list by using EIR is limited to 10 entries.

The EIR result list may contain information lead by the following identifiers:

| | |
|----------|--|
| Name | Bluetooth device name of the remote device |
| UUID16 | 16-bit UUIDs of provided service |
| UUID32 | 32-bit UUIDs of provided service |
| UUID128 | 128-bit UUIDs of provided service |
| MANUF | Manufacturer specific data |
| TX power | Transmit power |

Example:

| | |
|--------------|--|
| AT+BINQ, EIR | 008025087846 1F00 rssi -52 000272166186 3E0104 rssi -55 Name: WXP-TESTPC UUID16: 1101 0080250000AE 1F9C rssi -74 |
|--------------|--|

The result list in the example above contains EIR and normal inquiry data.

+BNAME Get Bluetooth Device Name of Remote Device

AT+BNAME <Bluetooth address>

This command gets the Bluetooth device name of a remote device.

In case the device is not discoverable the command responds with "NO CARRIER".

Example:

| Command | Response |
|-----------------------|-------------------|
| AT+BNAME 00802501D11A | BlueMod+B20 D1:1A |

| | |
|--------------|--------------------------------|
| +BSRV | Start Service Discovery |
|--------------|--------------------------------|

AT+BSRV <Bluetooth address>

This command starts a service discovery for given Bluetooth address. It responds with the remote device name, UUID, service channel number and the name of profile supported by this device (depending on the device it can be only one UUID or multiple UUID's).

The remote device name is limited to 31 characters. If the name of the remote device is longer than 31 characters, only the first 31 characters are shown.

The first line of the output is reserved for the remote device name. If the name request fails and the service request is successful, the first line in the output is empty.

In the example below "BlueRS+E/G2 D1:1A" represents the remote device name, "1101" the UUID, "1" the service channel number and "serial port" the name of profile.

If the service discovery fails the command responds with "NO CARRIER".

Example:

| Command | Response |
|----------------------|---|
| AT+BSRV 00802501D11A | BlueRS+E/G2 D1:1A 1101, 1, serial port OK |

| | |
|--------------|-------------------------------|
| +EDUT | Device Under Test Mode |
|--------------|-------------------------------|

AT+EDUT

This command sets the device to "device under test mode" for measuring and testing Bluetooth parameters. This mode stays active until the next reset of the device.

| | |
|-----------------|--------------------------------------|
| +SSPCONF | Secure Simple Pairing Request |
|-----------------|--------------------------------------|

AT+SSPCONF <Bluetooth address>, <value>

If a SSP is initiated and MITM is active (**S407=1**), depending on the I/O capabilities (**S406**) the AT interface generates an event SSPCONF and asks the user for confirmation.

Event: SSPCONF <Bluetooth address> <SSP passkey> ?

The user has to confirm the SSP passkey with the above command. If no confirmation is sent by the user within the bonding timeout (see **S348**) or in case of active reject, the SSP is rejected with NO CARRIER message.

| Value | Description |
|-------|--------------------|
| 0 | Reject SSP request |
| 1 | Accept SSP request |

+SSPPIN SSP Passkey Request

AT+SSPPIN <Bluetooth address>, <SSP passkey>

If a SSP is initiated and MITM is active (**S407=1**), depending on the I/O capabilities (**S406**) the AT interface generates an event SSPPIN and asks the user for the SSP passkey.

Event: SSPPIN <Bluetooth address> ?

The user has to answer this request with the SSP passkey displayed on the remote device.

Example:

| | |
|-------------------------------|---|
| AT+SSPPIN 008025135FB3,462069 | SSP passkey 462069 displayed on remote device 008025135FB3 |
|-------------------------------|---|

Event: SSPPIN <Bluetooth address> <passkey>

The user has to enter the displayed passkey at the remote device.

Deprecated commands

The following commands are available in the firmware for compatibility with older versions, but have no functionality anymore:

- S319
- S320
- S321

3 Restrictions

The local flow control is set to RTS/CTS and cannot be disabled. When using only VCC, GND and UART_Rx, UART_Tx serial lines, UART_CTS# should be set to active state (for further information please refer to the *BlueMod+B20 Hardware Reference*).

Note: It is strongly recommended to use hardware flow control. Not using flow control can cause a buffer overflow in the Bluetooth module which blocks the module. Furthermore a loss of data is possible.

The BlueMod+B20/BT2.1 only supports DCE mode.

4 Appendix

4.1 AT Result Codes

Result codes (numerical and verbose):

| Numeric | Text | Meaning |
|---------|------------|--|
| 0 | OK | Command completed |
| 1 | CONNECT | Connection established |
| 2 | RING | Indicates an incoming call (link request received) |
| 3 | NO CARRIER | General connection setup error, remote Bluetooth device not found (e.g. wrong address, out of range) |
| 4 | ERROR | Illegal command or error that cannot be indicated otherwise |
| 8 | NO ANSWER | Connection timed out (no response) |

4.2 Extended Result Codes

Extended result codes (numerical and text) are available after activation with **ATW1** command.

For the AT result code **CONNECT** the following extended result code is available:

CONNECT <Bluetooth address of remote device> <profile identifier (SPP/HID/OPPC)>

Example:

| | |
|------------------|-------------------------------|
| Numerical (ATV0) | 1 00802501D11A 1101 SPP |
| Text (ATV1) | CONNECT 00802501D11A 1101 SPP |

For the AT result code **RING** the following extended result codes are available:

RING <Bluetooth address of remote device> <uuid> <profile identifier (SPP/HID/OPPC)>

Example:

| | |
|------------------|----------------------------|
| Numerical (ATV0) | 2 00802501D11A 1124 HID |
| Text (ATV1) | RING 00802501D11A 1124 HID |

For the AT result codes **NO CARRIER** and **NO ANSWER** the following extended result codes are available.

NO CARRIER <Bluetooth release/error cause>

NO ANSWER <Bluetooth release/error cause>

General causes:

| Cause | Meaning | Result Code |
|-------|---|-------------|
| 0x01 | Unsuccessful due to a service search failure | NO ANSWER |
| 0x02 | Unsuccessful due to a service level connection failure | NO CARRIER |
| 0x03 | Unsuccessful due to service level connection already established | NO CARRIER |
| 0x04 | Unsuccessful due to RFCOMM connection failing to be established | NO CARRIER |
| 0x05 | Unsuccessful due to attempt to connect to unallocated server channel | NO CARRIER |
| 0x06 | Unsuccessful due to connection attempt timing out | NO ANSWER |
| 0x07 | Unsuccessful due to remote device rejecting connection | NO CARRIER |
| 0x08 | Unsuccessful due to remote device terminating the connection | NO ANSWER |
| 0x09 | Unsuccessful due to an abnormal disconnect while establishing a RFCOMM connection | NO CARRIER |

Authentication causes:

| Cause | Meaning | Result Code |
|-------|--|-------------|
| 0x11 | Authentication timed out | NO CARRIER |
| 0x12 | Authentication failed | NO CARRIER |
| 0x13 | Authentication failed due to too many repeat attempts | NO CARRIER |
| 0x14 | Authentication failed as remote device is not allowing pairing | NO CARRIER |
| 0x15 | Authentication failed as unit keys are not supported | NO CARRIER |
| 0x16 | Authentication failed as simple pairing is not supported | NO CARRIER |
| 0x17 | Authentication failed as host is already busy pairing | NO CARRIER |

SPP causes:

| Cause | Meaning | Result Code |
|-------|--|-------------|
| 0x20 | Successful disconnection | NO CARRIER |
| 0x21 | Disconnection occurred due to link loss | NO CARRIER |
| 0x22 | Disconnect attempt failed, no service level connection | NO CARRIER |
| 0x23 | Disconnect time out | NO CARRIER |
| 0x24 | Unsuccessful for some other reason | NO CARRIER |

OPPC causes:

| Cause | Meaning | Result Code |
|-------|--|-------------|
| 0x50 | Last operation was successful | NO CARRIER |
| 0x51 | Last operation failed | NO CARRIER |
| 0x52 | A command has been attempted while another command is already running | NO CARRIER |
| 0x53 | A command has been attempted while a different multi-packet command is running | NO CARRIER |
| 0x54 | Operation failed due to being in the wrong state | NO CARRIER |
| 0x55 | OBEX bad request | NO CARRIER |
| 0x56 | Request forbidden | NO CARRIER |

| | | |
|------|-------------------------|------------|
| 0x57 | OBEX command not found | NO CARRIER |
| 0x58 | OBEX connection aborted | NO CARRIER |

HID causes:

| Cause | Meaning | Result Code |
|--------------|---|--------------------|
| 0x60 | Successful connection | NO CARRIER |
| 0x61 | Connection failed | NO CARRIER |
| 0x62 | Out of resource | NO CARRIER |
| 0x63 | Timeout waiting for connection | NO CARRIER |
| 0x64 | Disconnected remotely during setup | NO CARRIER |
| 0x70 | Successful disconnection | NO CARRIER |
| 0x71 | Unsuccessful due to the link being lost | NO CARRIER |
| 0x72 | Unsuccessful due to time out | NO CARRIER |
| 0x73 | Disconnection due to protocol violation | NO CARRIER |
| 0x74 | Unsuccessful for some other reason. | NO CARRIER |
| 0x75 | Virtual unplug disconnection | NO CARRIER |

5 History

| Version | Release Date | By | Change description |
|---------|--------------|----|---|
| r01 | 15.12.2010 | TA | Based on BlueMod+B2x SPP AT Command Reference r13, Added new commands for Bluetooth 2.1 support: - S406: I/O Capabilities - S407: Man in the Middle Protection - AT+SSPCONF: Secure Simple Pairing Request - AT+SSPPIN: SSP Passkey Request, Added EIR in +BINC command, S319, S320, S321 commands not applicable for Bluetooth 2.1 anymore, moved to section "Deprecated commands", Added modified bonding timeout in S348 command, Adjusted description of ATD and S318 commands to Bluetooth 2.1 requirements, Added table with extended result codes for NO CARRIER and NO ANSWER messages, Corrected RSSI value in unconnected state in S346 register, Moved description of maximum length of bonded device list from +BBND to +BBTL, Added new command S312: Name Discovery during Inquiry |
| r02 | 20.10.2011 | TA | Corrected description of S311 command Corrected example of S302 command, Added HID profile in S314 register, Added new command S409: Deep Sleep, Added new profile identifier SPP and HID for outgoing call in ATD command description, Removed AT? command, no longer supported |
| r03 | 22.12.2011 | TA | Ignoring special characters in ATD command is no longer supported, Revised description of S314: Own Service Profiles, Added table of minor device classes for peripheral (HID) devices in S302 register, Added new command S408: SSP Debug Mode, Revised description of S409: Deep Sleep, Revised description of ATW and chapter "Result Codes", added new profile identifier SPP/HID, Added response message in ATO command, Revised description of AT result codes, Added examples (numerical and verbose) in chapter "Extended Result Codes", Corrected cross reference in +BBND and +BBTA command |
| r04 | 02.03.2012 | TA | Added a reference to the BlueMod+B20/BT2.1 User Guide, Renamed S409 into "Power Down", Removed headset profile in S314, no longer supported, SSP matrix from S407 moved to user guide |

| | | | |
|-----|------------|----|---|
| r05 | 11.04.2012 | TA | Added new commands: - S410: Out of Range Detach - S411: RSSI Value for Out of Range Detach - S412: RSSI Poll Time, Added new profile identifier OPPC for OBEX connection in ATD command description, Chapter "Remote Configuration" moved to user guide |
| r06 | 02.01.2014 | TA | Added note to S402 that escape sequence detection applies to SPP and OPP profile only, Added profile specific causes for extended result codes, Removed S342 "HSAG Remote Bluetooth Address", it is no longer supported |
| r07 | 07.01.2015 | TA | Added value range of S411 command Revised description of S412 command |
| r08 | 25.05.2016 | BG | Telit cover page added |

Telit Wireless Solutions GmbH
Mendelssohnstraße 15 D
22761 Hamburg
Germany

Phone: +49 (0)40 890 88-0
Fax: +49 (0)40 890 88-444
E-mail: ts-srd@telit.com
www.telit.com



SUPPORT INQUIRIES

Link to www.telit.com and contact our technical support team for any questions related to technical issues.

www.telit.com



Telit Communications S.p.A.
Via Stazione di Prosecco, 5/B
I-34010 Sgonico (Trieste), Italy

Telit Wireless Solutions Inc.
3131 RDU Center Drive, Suite 135
Morrisville, NC 27560, USA

Telit Wireless Solutions Ltd.
10 Habarzel St.
Tel Aviv 69710, Israel

Telit IoT Platforms LLC
5300 Broken Sound Blvd, Suite 150
Boca Raton, FL 33487, USA

Telit Wireless Solutions Co., Ltd.
8th FL., Shinyoung Securities Bld.
6, Gukjegeumyung-ro8-gil, Yeongdeungpo-gu
Seoul, 150-884, Korea

Telit Wireless Solutions
Technologia e Servicos Ltda
Avenida Paulista, 1776, Room 10.C
01310-921 São Paulo, Brazil

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2016, Telit